


# GraverHone VS

## OPERATION AND MAINTENANCE MANUAL



### IMPORTANT NOTICE FOR OPERATORS

**No user serviceable parts inside.** Do not remove any outer surfaces. Do not modify this equipment or remove warning labels. Modifications can increase risks to the operator. Do not use this equipment if it is damaged. Always wear sufficient eye protection. Take appropriate steps to avoid dust inhalation by using a respirator.

**Tools may become hot while operating this unit as intended.** Protect skin and surfaces from burns or damage. **Tools can be extremely sharp after this unit is used as intended.** Protect skin and surfaces from punctures, cuts, or damage.

### REQUIRED EQUIPMENT

- A respirator (breathing protection).

The dust created while sharpening some tool materials may present a health risk.

- Eye protection.

### SETUP

#### ATTACH DRIVE PLATE & WHEEL (FIG. 2)

Place drive plate (G) on spindle (F). Place metal washer (H) in inset at center of drive plate. Thread bolt (I) into center of drive plate and secure on spindle. Tighten with 12 mm wrench. Place wheel on drive plate. Align and place quick lock knob and spring (J) assembly over bolt. Push down and twist into locking position.



#### CONNECT ELECTRICAL POWER (FIG. 3)

Insert the converter cord into receptacle on unit (FIG 3.1). Connect the electrical power cord into the 24-volt power converter (FIG 3.2). Connect the 3-prong power cord into a properly grounded power outlet.

### OPERATION

Press power on/off button to power unit on. (FIG. 1 A). **Unit must not be in operation while installing or removing sharpening wheel.** If not installed, attach wheel securely on drive plate (FIG. 1 G). Position RPM dial to desired RPM setting (FIG. 1 D).

Set rotation switch to clockwise (FIG. 1 C) or counter-clockwise (FIG. 1 B) as desired. When finished, set rotation switch to center “off” position. When finished, press power on/off button to power unit off. (FIG. 1 A).





---

## **MAINTENANCE**

To maintain this unit, keep all surfaces free of dust and debris with regular cleaning using a damp cloth. Take appropriate measures to avoid inhaling dust while cleaning.

---

## **SERVICE & REPAIR**

Please call GRS or an authorized GRS dealer for service and repair. Unauthorized servicing will void the 2-year warranty. **This unit is not serviceable by the operator and must be sent in to GRS or an authorized GRS dealer for repair.**

---

## **WARRANTY**

Each GraverHone VS carries a full 2-year warranty covering parts and labor. Contact GRS or an authorized GRS dealer before returning any equipment.

**Customer Support Email:** [support@glendo.com](mailto:support@glendo.com)

**Website Support Form:** <https://www.grs.com/customer-service/>

---

Printed in USA. Products made in USA. © 2017 Glendo LLC. All rights reserved.

---



### **Glendo LLC**

900 Overlander Road  
Emporia, KS 66801 USA

Phone: +1-620-343-1084

Fax: +1-620-343-9640

E-mail: [glendo@glendo.com](mailto:glendo@glendo.com)

<https://www.grs.com>